

TONNEAU COVER FITTING INSTRUCTION

FORD FALCON

XD XE XF XG XH SINGLE CAB

1979 – 1999

PART NO: ATB01002

BASIC TOOLS REQUIRED

Drill, 4mm Drill Bits, Rivet Gun, Marking Pencil/ Pen

CONTENTS

- 1 x Tonneau Cover
- 2 x Support Bars
- 1 x Fitting Instruction
- 4 x Bar Brackets
- 8 x Rivets

1. INSTALLATION PROCEDURE

NOTE Read entire instructions prior to start.

- STEP 1** Fit the front of the Tonneau to the front of the Ute tub placing the LTD clips (Fitted on the Tonneau Cover) on to the LTD posts already fitted on the body.
(Behind rear windscreen).
- STEP 2** Fit your tonneau cover support bar/s into position (Refer to the instructions below)
- STEP 3** Drape cover over support bars.
- STEP 4** Fit Bunji Loops to Body Hooks, starting at the rear then fitting the side's bunjis.
- STEP 5** Your Tonneau Cover is now fitted.

2. MULTI-FIT SUPPORT BAR

The Aussie Tonneau Multi - Fit Support Bar is designed to fit almost all Utes on the Market, from Suburu Brumbys to Cab Chassis aluminium trays.

2.1 BASIC TOOL REQUIRED

- Drill, 4mm drill bit

2.2 MULTI-FIT SUPPORT BAR CONTENTS

- 1 x hollow bar centrepiece
- 2 x grub screws
- 2 x solid bar end piece

2.3 FITTING MULTI-FIT BAR

1. Insert solid bar pieces into either end of hollow tube. Adjust bar so it fits between bar bracket holders with the holes facing to the ground (so the grub screws don't rub against the tonneau), as shown above and then with a white pencil make a mark through the small holes of the hollow bar onto the solid ends. This is where you will drill a hole to the depth of about 1-2mm (do not go any further)
2. Join the pieces back together and screw grub screws through the hollow bar into the holes that you drilled. **Make sure you do not over tighten the grub screws.** Refit the bar. You may kink the bar in the middle to give it some extra height to assist with water runoff.