

# **Fitting Instruction**

**Clip On Soft Tonneau Cover**

**Part No. ATC01146**

**Volkswagen Amarok Dual Cab  
Without Sport Bar Model**

# Installation Instruction

Please note before fitment:





- Read all instructions prior to fitting the Tonneau cover.
- Check that the fitting kit is complete before beginning the installation.
- If replacing any other cover all hardware must be replaced with hardware supplied.

## Safety Notes


- Ensure that appropriate Personal Protective Equipment is used.
- Always refer to vehicle's work shop manual when removing components.



## Parts Supplied

Tonneau Cover x 1	Ropetrack x 1	Tailgate Rail x 1	Side Rail x 2	Support Bar x 1
				
Support Barbrack x 2	Rivets x 21	Shock Cord x 1 Rope Hook x 5 Washer x 2		
				

## Tools Required

Drill	Pop Rivet Gun	Tape Measure	Pencil/ Marker	4mm Drill Bit
				

## 1. Attaching Ropetrack

- a. Place the 2 pieces of dowel in the ends of the ropetrack.
- b. Rest the aluminum ropetrack (Dowel pieces) on the side rails of Tub, ensure the flat side of the ropetrack is the surface facing the back of the tub, with the 'C' channel sitting on top of the front of the tub. Centralise the ropetrack. *Figure 1*
- c. Using a 4.5 mm drill bit, drill 5 holes evenly spaced through the aluminium ropetrack into the front of tub.
- d. The first hole at each end should be 50mm from the edge of the aluminium ropetrack. *Figure 2*
- e. Place a 4mm rivet in each hole as it is drilled, but do not rivet. Once all holes have been drilled, remove the rivets and ropetrack and clean any swarf.
- f. Remove the ropetrack and discard the two pieces of dowel.
- g. Apply rust inhibitor to the drilled holes in the tub and apply a bead of silicon to the ropetrack along the line of the holes. *Figure 3*
- h. Place the ropetrack back into position and rivet ropetrack into place.

Figure 1





Figure 2



Figure 3



## 2. Attaching Side Rails

- a. Attach the side aluminium rails (1360mm Long): Align the inside edge of the rail with the inside driver's side edge of the tub pushing the side rail up against the ropetrack (already fitted). Keep the rail square, flush on top of the tub. *Figure 4*
- b. From the front edge of the side rail Measure and mark the following locations, 25mm up from bottom edge:  
  
70mm, 365mm, 660mm, 692mm, 985mm and 1310mm  
onto the side rail with the Non-permanent marking pen.

Figure 4





Figure 5




**IMPORTANT:** Keep ALL Rails flush with top of the Tub Walls and Tailgate while drilling.

c. Drill each of the marked locations through the aluminium and into the inside edge of the tub. And rivet into 70mm, 365mm, 985 and 1310mm.

d. Attach the bar bracket by placing a 4mm rivet through each hole of the bracket and into the centre holes in the rail. Rivet into place. *Figure 6*

e. Apply rust inhibitor and rivet the front and rear holes to complete attachment of side rail.

f. Repeat those steps for the passenger's side.




### 3. Attaching Support Bar

a. Undo grub screws on the hollow tube, then insert solid bar pieces into either end of hollow tube.

b. Place the bar into the bar brackets (*see Figure 7*) and centre the hollow tube in the middle of the tub.

c. Adjust the hollow tube so the screws are facing the tub floor. This prevents the grub screws rubbing against the tonneau cover.


d. Tighten the grub screws to secure the hollow tube into place.



### 4. Attaching Tailgate


a. Centre the aluminium rail on the tailgate and mark the tailgate for future reference (*see Figure 8*).

Figure 8



b. Measure and mark all 5 points on the aluminium rail (*see Figure 9*) then drill out all 5 using a 4mm drill bit. We recommend drilling just the aluminium rail in this step.

Figure 9



c. With the aluminium now drilled, place it back onto the tailgate and re-centre, aligning with the previously measured centre mark.

d. Drill through all 5 holes into the tailgate with the 4mm drill bit. And utilising the rivets provided, use your rivet gun to rivet the rail in at all 5 locations.

## 5. Fit The Tonneau Cover

- Slide the front rope of the tonneau cover into the ropetrack and centre the cover then drape the cover over the head board. *Figure 10*
- Clip the driver's side of the cover onto the driver's side rail then attach the passenger side of the cover using the plastic's edge in the corners to help stretch the cover.
- Clip the plastic onto the tailgate rail using the plastic's edge in the corners to help stretch the cover.
- To remove cover once fitted peel cover away from Aluminium clip in rail by peeling away from the edge of the plastic. *Figure 11*

**IMPORTANT:** Do not use cover corners to lift. Always use plastic edges.

Figure 10






Figure 11




## 6. How To Fit Internal Shock Cord

- Tie a knot in one end of the shock cord
- Pull shock cord through all the plastic hooks.
- Feed the shock cord through the loops on the cover.
- Tie a knot at the other end.
- Space the hooks as required.
- Use washers to tie off the shock cord.


Tie a knot in each end of the shock



Feed cord through all loops



Hooks placement and direction



## 7. Warranty And Feedback

### Send Us A Photo Of Your Fitted Cover

Happy with how your tonneau turned out? Please email us a photo of your ute to: [sales@aussietonneaus.com.au](mailto:sales@aussietonneaus.com.au)



Please try and replicate this angle when taking a photo – thanks in advance for contributing!

### **How To Easily Attach & Detach Your Clip On Cover**



No more ugly pull tabs, tearing covers, or needing Arnold-like strength with this method!

- Visit the following link: <http://bit.ly/AT-CLIP>
- Or simply scan the QR code. Open your camera app and point it here to see the video! → → →

