

# Tonneau Cover Fitting Instructions

**Volkswagen Amarok Dual Cab  
Without Sport Bar  
(Genuine Hardware Fitted)  
2011 – Current**


**Part number: ATC01346**

<b>Package includes</b>	
1 x Tonneau Cover	5 x Rope Hooks
1 x Shock Cord	2 x M8 Washers
1 x Fitting Instruction	

**NB: This item is tonneau cover only.**

# TONNEAU COVER FITTING

1. To attach the cover, slide the front rope of tonneau cover into the ropetrack channel and centre the cover. **See Figure 1**
2. Pull and drape the cover across the tub.
3. Clip the side plastics under the aluminium profile first using the pull loops in the corners to stretch the cover.
4. Clip the plastic on the tailgate under the aluminium profile last. **See Figure 2**



## Using Internal Elastic Shock Cord:


The plastic clips on the internal shock cord can be hooked into the aluminium extrusions so that the cover can still be secured with larger loads in the tub.

**Your Tonneau is ready for work.**

## How to Fit Internal Elastic Shock Cord

(To be used for covering larger loads)

- Tie a knot in one end of the shock cord
- Pull shock cord through the plastic hooks
- Feed shock cord through loops on the cover
- Tie a knot at the other end
- Space the hooks as required
- Use the washers to tie off rope



Tie a knot in each end of the rope



Hook placement and direction



