

TONNEAU INSTALLATION INSTRUCTIONS

FORD RANGER PX DUAL CAB WITH HEADBOARD (CHECK IMAGE)

NOV 2011 – MAY 2013

PART NUMBER: ATB01018

BASIC TOOLS REQUIRED

- Rivet gun, Drill, 4.5mm Drill bit, Measuring tape, Silicon sealant, Anti-corrosive primer.

CONTENTS

1 x Tonneau cover	3 x Aluminium rope track (403mm)
2 x Bar Brackets	1 x Tonneau support bar
18 x Buttons	30 x Rivets
4 x Pieces of dowel	2 x 100mm Angle


(Some parts in the fitting kit may not be required. All fitting kits are weighed to ensure accurate quantities.)

1. INSTALLATION PROCEDURE


– IMPORTANT –

THE HEADBOARD ON THIS VEHICLE WAS CHANGED IN MAY 2013.

PLEASE REFER TO THE IMAGE BELOW TO CONFIRM THE HEADBOARD ON THE VEHICLE MATCHES THE IMAGE ON THE LEFT HAND SIDE.



Suits This Style Headboard



Does Not Suit This Style Headboard

NOTE: Read entire instructions prior to start.

- STEP 1** Fit the pieces of angle to the outside edge of the head board making sure the top flat edge of the angle is at the same height as the top lip of the head board. Drill two 4mm holes in each piece of angle, silicone behind it, then rivet into place
- STEP 2** Using two pieces of dowel, join the 3 aluminum rope tracks together. Place the other 2 pieces of dowel in the ends of the now joined rope track.
- STEP 3** Rest the aluminum rope track on the pieces of angle already fixed in place, and push forward to the vertical face of the head board.
- STEP 4** Using a 4 mm drill bit, drill 6 holes 50mm from the end of each of the aluminum rope tracks into the front of tub.
- STEP 5** Once all the holes have been drilled, remove the dowelling pieces. Squeeze silicon sealant along the back of the rope tracks and pop rivet into place.
- STEP 6** Slide the front of the tonneau cover through the aluminium rope track section
- STEP 7** To fit the bar brackets, measure 743mm back from the inside front edge at the top of the tub and place them as shown in Figure 2. (5mm down from top edge of tub) Drill and rivet using two large rivets for each Bar Bracket. Install the support bar according to the supplied instructions.
- STEP 8** To fit round body hooks to the tail gate, measure 465mm up from the bottom edge of the tail gate and line up each hook individually to each bunji loop starting with the two either side of the tailgate handle and working your way to the outside, drill and rivet buttons alternating from side to side.

STEP 9 To fit round body hooks to the sides of the tub measure 155mm down from the inside edge and line up each hook individually to each bunji loop. Start with the two rear bunjis and work your way around to the front, drill and rivet buttons alternating from side to side.

STEP 10 Your Tonneau Cover is now fitted.

Insert a dowel [J] half way into each end of the rope track [E].

Ensuring the rounded section (1) of the rope track faces away the cabin, sit the rope track against the front (cabin end) inside vertical surface of the tub (2) & centralise the rope track.




Figure 1




Figure 2

2. CARING FOR YOUR TONNEAU

Apply bee's wax or Dri-lube to the stitching a few times a year, as this will maintain the tonneau's waterproofing ability and prevent the stitching from degrading. Use a mild detergent and soft scrubbing brush to clean tonneau.

Never drive without tonneau support bars in place as the flapping can cause a delaminating effect on the material.

"Tonneau is not designed to be used as a load restraint"

3. MULTI-FIT SUPPORT BAR

The Aussie Tonneau Multi - Fit Support Bar is designed to fit almost all Utes on the Market, from Suburu Brumbys to Cab Chassis aluminium trays.

3.1 BASIC TOOL REQUIRED

- Drill, 4mm drill bit

3.2 MULTI-FIT SUPPORT BAR CONTENTS

- 1 x hollow bar centrepiece
- 2 x grub screws
- 2 x solid bar end piece

3.2 FITTING MULTI-FIT SUPPORT BAR

1. Insert solid bar pieces into either end of hollow tube. Adjust bar so it fits between bar bracket holders with the holes facing to the ground (so the grub screws don't rub against the tonneau), as shown above and then with a white pencil make a mark through the small holes of the hollow bar onto the solid ends. This is where you will drill a hole to the depth of about 1-2mm (do not go any further)
2. Join the pieces back together and screw grub screws through the hollow bar into the holes that you drilled. **Make sure you do not over tighten the grub screws.** Refit the bar. You may kink the bar in the middle to give it some extra height to assist with water runoff.