

# TONNEAU COVER FITTING INSTRUCTION

Great Wall Dual Cab V200/ V240

2009 – 2015

Part Number: ATB01141

## 1. TONNEAU COVER FITTING

NOTE: Read entire instructions prior to start.

### 1.1 BASIC TOOL REQUIRED

Drill, 4mm Drill Bit, Tape Measure, Rivet Gun, Marking Pencil / Pen, Clear Silicone / Silicone Gun

### 1.2 CONTENTS

1 x Tonneau Cover	2 x Bar Brackets
1 x Aluminium Rope Track (with Shim)- 1462mm long	28 Rivets
1 x Tonneau Support Bar	2 x Dowel
16 x Rope Buttons	

### 1.3 TONNEAU COVER INSTALLATION PROCEDURE

1. Using two pieces of dowel, place the dowel in the ends of the rope track. Rest the aluminum rope track on the side rails, ensure the flat side of the rope track is the surface positioned against the tub face. **See Figure 1**
2. Using a 4mm drill bit, drill a hole 15mm from each end of the aluminum rope track, 1 hole in the center of the rope track and 1 hole each side in the middle of the centre. Place a 4mm rivet in each hole as it is drilled. **DO NOT RIVET YET.** Once all holes have been drilled, remove the rivets, rope track and dowels.
3. Apply a bead of clear silicone along the centre of the front edge of the rope track (the side that contacts the tub).
4. Rivet the aluminium rope track into position & remove Dowel pieces (Taping out might be required).
5. With a pencil mark the inside edge on each side of the tub at 691mm from the inside front face of tub towards the rear on each side. Centrally locate the bar bracket over this position and align the top of the bar bracket 5mm down from the top edge of the tub and drill and rivet bracket into place. **See Figure 2.** Repeat for other side of tub. Fit tonneau support bar to bar brackets.
6. Slide the front of the tonneau cover through the aluminium rope track section.
7. **Ensure tonneau is centre.** To fit the rope buttons to the tub, start with the tailgate, vertically line up each button to each bunji loop starting with the two either side of the tailgate handle.


The height for the buttons on the tailgate is 175mm down from the **INSIDE EDGE** of the tailgate. Work from the centre out, alternating from side to side. Attach each bunji to the button as it is fitted.

- To fit the rope buttons to the sides vertically line up each button to each bunji loop starting from the rear bunji loop, alternating from side to side working towards the front. The height for the side rope buttons are all measured down 175mm from the **INSIDE EDGE** of the tub. Attach each bunji to the button as it is fitted.

**NOTE:** All measurements are to be taken from the **TOP INSIDE EDGE** of the tub.

Insert a dowel [J] half way into each end of the rope track [E].


Ensuring the rounded section (1) of the rope track faces away the cabin, sit the rope track against the front (cabin end) inside vertical surface of the tub (2) & centralize the rope track.



**Figure 1**

Placement of aluminium rope track.

Ensure channel is above the tub's top edge.



**Figure 2**

Placement of bar bracket.

## 2. CARING FOR YOUR TONNEAU

Apply bee's wax or Dri-lube to stitching a few times a year, as this will maintain the tonneau's waterproofing ability and prevent the stitching from degrading. Use a mild detergent and soft scrubbing brush to clean tonneau.

Never drive without tonneau support bars in place as flapping can cause a delaminating effect on the material.

"Tonneau is not designed to be used as a load restraint"

## 3. MULTI-FIT SUPPORT BAR

The Aussie Tonneau Multi - Fit Support Bar is designed to fit almost all Utes on the Market, from Suburu Brumbys to Cab Chassis aluminium trays.

### 3.1 BASIC TOOL REQUIRED

Drill, 4mm drill bit

### 3.2 MULTI SUPPORT BAR CONTENTS

- 1 x hollow bar centrepiece
- 2 x grub screws
- 2 x solid bar end piece

### 3.3 FITTING MULTI SUPPORT BAR

1. Insert solid bar pieces into either end of hollow tube. Adjust bar so it fits between bar bracket holders with the holes facing to the ground (so the grub screws don't rub against the tonneau), as shown above and then with a white pencil make a mark through the small holes of the hollow bar onto the solid ends. This is where you will drill a hole to the depth of about 1-2mm (do not go any further)
2. Join the pieces back together and screw grub screws through the hollow bar into the holes that you drilled. Make sure you do not over tighten the grub screws. Refit the bar. You may kink the bar in the middle to give it some extra height to assist with water runoff.