

# TONNEAU COVER FITTING INSTRUCTION

## FORD FALCON AU BA BF

### WITH NARROW FACTORY SPORT BAR

### 1999 – MAY 2008

### PART NO: ATB01223

#### BASIC TOOLS REQUIRED

Drill, 4mm Drill Bits, Rivet Gun, Marking Pencil/ Pen

#### CONTENTS

- |                           |                    |
|---------------------------|--------------------|
| - 1 x Tonneau Cover       | - 4 x Bar Brackets |
| - 2 x Tonneau Support Bar | - 8 x Rivets       |
| - 1x Fitting Instruction  |                    |

## 1. INSTALLATION PROCEDURE

#### NOTE

Read entire instructions prior to start.

- |               |  |
|---------------|--|
| <b>STEP 1</b> | Fit the front of the Tonneau to the front of the ute tub placing the Plastic Retainers (Fitted on the Tonneau Cover) on to the Metal Lip on the Steel Body (Not the Plastic Ute Liner) between the cabin and the Ute Body. (Behind rear windscreen). |
| <b>STEP 2</b> | Fit your tonneau cover support bar/s into position. Place cover onto the support bar before fitting.   |
| <b>STEP 3</b> | Drape cover over support bars.   |
| <b>STEP 4</b> | Fit Bunji Loops to Body Hooks, starting at the rear then fitting the sides bunjis.   |
| <b>STEP 5</b> | Clip straps around Sports Bars   |
| <b>STEP 6</b> | Your Tonneau Cover is now fitted.  |

## 2. MULTI-FIT SUPPORT BAR

The Aussie Tonneau Multi - Fit Support Bar is designed to fit almost all Utes on the Market, from Suburu Brumbys to Cab Chassis aluminium trays.

### 2.1 BASIC TOOL REQUIRED

- Drill, 4mm drill bit

### 2.2 MULTI-FIT SUPPORT BAR CONTENTS

- 1 x hollow bar centrepiece
- 2 x grub screws
- 2 x solid bar end piece

### 2.3 FITTING MULTI-FIT BAR

1. Insert solid bar pieces into either end of hollow tube. Adjust bar so it fits between bar bracket holders with the holes facing to the ground (so the grub screws don't rub against the tonneau), as shown above and then with a white pencil make a mark through the small holes of the hollow bar onto the solid ends. This is where you will drill a hole to the depth of about 1-2mm (do not go any further)
2. Join the pieces back together and screw grub screws through the hollow bar into the holes that you drilled. **Make sure you do not over tighten the grub screws.** Refit the bar. You may kink the bar in the middle to give it some extra height to assist with water runoff.