

TONNEAU COVER FITTING INSTRUCTION

MITSUBISHI MQ/ MR DUAL CAB

WITHOUT SPORT BAR & HEADBOARD

JULY 2015 – CURRENT

PART NO: ATB01255

BASIC TOOLS REQUIRED

Drill, 4mm Drill Bits, Rivet Gun, Marking Pencil/ Pen

CONTENTS

- 1 x Tonneau Cover
- 1 x Tonneau Support Bar
- 2 x Angle Aluminium
- 1 x Fitting Instruction
- 2 x Bar Brackets
- 34 x Rivets
- 18 x Rope Buttons

1. INSTALLATION PROCEDURE

1. Place the 50 x 25mm angle on the front top edge of the Ute.
The 50mm wall of the angle needs to be vertical. Align the vertical face of the angle with the inside edge of the tub. *See Figure 1*
2. Drill 5 evenly spaced holes through the 25mm section of the angle and into the top edge of the tub. The first hole from each end will be about 50mm from the end of the angle. Pop rivet into place with 5 rivets.
3. Sit and centralize the 20 x 20mm angle on top of the 50 x 25mm angle. *See Figure 2*
4. Drill 5 evenly spaced holes through the smaller angle, into the larger one already fitted. The first hole needs to be 30mm from each end.
5. Pop rivet the smaller angle to the larger one using 5 rivets.

Figure 1







Figure 2




6. To fit the bar brackets, measure 735mm back from the inside front edge at the top of the tub and place them as shown in **Figure 3**. (15mm from top edge of tub). Drill and rivet using two large rivets for each Bar Bracket.




7. Refer to Section 2 to fit support bar.
8. To attach the cover, clip the front 'J' retainer onto the angle fitted to the front edge of the tub and drape the cover across the tub. **See Figure 4**



9. To fit the rope buttons to the tailgate measure 455mm up from the bottom edge on both sides of the tailgate and mark. With a straight edge draw a line between these two marks. **See Figure 5**
10. Centre the cover and mark the position of each bunji loop on the line drawn in step 9.



11. With a 4 mm drill bit drill holes in these positions and pop rivet and a rope button to the tailgate. Attach the rear bunji loops to the buttons as you go. **See Figure 6**



12. To fit the rope buttons to the sides of the tub measure and mark 160mm from the inside edge of the tub down the outside. **See Figure 7**



13. From where the last bunji is situated on each side measure and mark 120mm from the inside edge at the front of the tub down the outside.

14. With a straight edge draw a line between the two positions marked in step 12 and 13. On this line mark the positions of each side bunji except for the front bunji on each side.

15. For this bunji place a mark on the line 50mm from the front of the tub. **See Figure 8**

16. With a 4mm drill bit drill holes in these positions and pop rivet a rope button to the side.

17. Attach the bunji loops to the buttons when attached alternating from left to right working your way to the rear of the tub.



2. MULTI-FIT SUPPORT BAR

The Aussie Tonneau Multi - Fit Support Bar is designed to fit almost all Utes on the Market, from Subaru Brumbys to Cab Chassis aluminium trays.

2.1 BASIC REQUIRED TOOLS

- Drill, 4mm drill bit

2.2 MULTI-FIT SUPPORT BAR CONTENTS

- 1 x hollow bar centrepiece
- 2 x grub screws
- 2 x solid bar end piece

2.3 FITTING MULTI -FIT BAR

1. Insert solid bar pieces into either end of hollow tube. Adjust bar so it fits between bar bracket holders with the holes facing to the ground (so the grub screws don't rub against the tonneau), as shown above

and then with a white pencil make a mark through the small holes of the hollow bar onto the solid ends.

This is where you will drill a hole to the depth of about 1-2mm (do not go any further)

2. Join the pieces back together and screw grub screws through the hollow bar into the holes that you drilled. **Make sure you do not over tighten the grub screws.** Refit the bar. You may kink the bar in the middle to give it some extra height to assist with water runoff.