

Tonneau Cover Fitting Instructions

VE VF Commodore

To Suit Sports Bar

2007 - Current

Part Number: ATC01260

Package includes

1 X Tonneau cover	1 x Fitting Instructions
1 x Commodore Extrusion	2 x Black Support Bars
2 x End Caps for Extrusion	

1. TONNEAU COVER FITTING

- Fit the two Support Bars into the designated holes in the tub liner. The longer bar is the front bar, the shorter one is for the back.
- To fit the front extrusion, have the front plastic inserted into the centre groove of the extrusion.
- Slide the aluminium with the end caps vertically up into the recessed notches behind the cab.
- Once the extrusion is all the way up on both sides, rotate it 90 degrees so the plastic sewn into the cover is on the top.
- The extrusion then slides back towards the tailgate to lock it into position.

2. MULTI-FIT SUPPORT BAR

The Multi - Fit Support Bar is designed to fit almost all Utes on the Market, from Suburu Brumbys to Cab Chassis aluminium trays.

2.1 BASIC TOOL REQUIRED

Drill, 4mm drill bit

2.2 MULTI-FIT SUPPORT BAR CONTENTS

- 1 x hollow bar centrepiece
- 2 x grub screws
- 2 x solid bar end piece


2.3 FITTING MULTI-FIT BAR

1. Insert solid bar pieces into either end of hollow tube. Adjust bar so it fits between bar bracket holders with the holes facing to the ground (so the grub screws don't rub against the tonneau), as shown above and then with a white pencil make a mark through the small holes of the hollow bar onto the solid ends. This is where you will drill a hole to the depth of about 1-2mm (do not go any further)
2. Join the pieces back together and screw grub screws through the hollow bar into the holes that you drilled. **Make sure you do not over tighten the grub screws.**
3. You may kink the bar in the middle to give it some extra height to assist with water runoff.


3. HOW TO FIT INTERNAL ELASTIC SHOCK CORD

- Tie a knot in one end of shock cord.
- Pull shock cord through all plastic hooks.
- Feed the shock cord through loops on the cover.
- Tie a knot at the other end
- Space the hooks as required
- Use washers to tie off rope


Tie a knot each ends of rope



Feed cord through all loops



Hook placement and direction



Using Internal Elastic Shock Cord:

The plastic clips on the internal shock cord can be hooked into the aluminium extrusions so that the cover can still be secured with larger loads in the tub.