

LDV T60

Clip On Soft Tonneau Cover

Dual Cab with Sport Bar and Liner

Fitting Instruction

2017 – Current












Part No. ATC01296

Installation Time: 1 Hour

Parts and tools.

Check the contents of the kit prior to fitment.

Supplied parts.

<p>Ropetrack x 1(1565mm)</p> 	<p>Tailgate Rail x 1(1400mm)</p> 	<p>Rear Side Rail x 2(710mm)</p> 	<p>Front Side Rail x 2 (515mm)</p> 
<p>Support Bar x 1</p> 	<p>Tonneau Cover x 1</p> 	<p>Bar Brackets x 2</p> 	<p>4mm Rivet x 24</p> 
<p>Internal Shock Cord x 1</p> 	<p>Rope Hooks x 5</p> 	<p>Fitting Instruction x 1</p> 	





Installation Procedure

1. Ropetrack


- (a) Rest the aluminium rope track on the top of the front edge of the Tub, with the 'C' channel facing the cabin. Centralise the rope track. (See figure 1)
- (b) Using a 4.5 mm drill bit, drill 5 holes evenly spaced through the aluminium rope track into the tub. The first hole at each end should be 100mm from the edge of the aluminium rope track. (See Figure 2)
- (c) Place a 4mm rivet in each hole as it is drilled, but do not rivet. Once all holes have been drilled, remove the rivets and ropetrack and clean any swarf.
- (d) Apply rust inhibitor to the drilled holes in the tub and apply a bead of silicon to the ropetrack along the line of the holes. (See Figure 3)
- (e) Place the ropetrack back into position and rivet ropetrack into place.

2. Attach Front Side Aluminium Rail

- (a) Clean the top surface of the driver's side of the tub with a damp rag. Allow to dry. Remove the red backing tape from the underside of one of the side profiles.
- (b) Centre the rail between the sports bars. Ensure the aluminium is square and flush with the top of the tub.
- (c) Measure and mark a spot 50mm from each end and one in the middle, 30mm up from the bottom edge of the rail.



- (d) Drill through these locations into the tub using a 4.5mm drill bit. Then rivet into place.




3. Attach Rear Side Aluminium Rail


- (a) Clean the top of the tub with the dump rag and allow it to dry. Remove the red backing tape from the underside.

NOTE: Side Rails need to sit behind Tie Downs, loosen Tie Downs so that the rails can sit flush with the side of the tub.

- (b) Locate the Side Extrusion (710mm) hard up against the front edge of the tub with the notch to the rear.
- (c) Slide each the profile down keeping it square with the top of the tub.
- (d) From the front edge of the rail, 30mm from the bottom edge, measure and mark the following locations:




- 20mm, 52mm, 305mm and 560mm



- (e) Drill each of the marked locations through the aluminium and into the inside edge of the tub.
- (f) And then rivet into 305mm and 560mm.



- (g) Attach the bar bracket by placing a 4mm rivet through each hole of the bracket and rivet into the remaining holes, 20mm and 52mm.



❖ Repeat those instruction for the other side.

(4). Attach the Tailgate Aluminium Rail


- (a) Clean the top of the tailgate of the tub with the dump rag and allow it to dry. Remove the red backing tape from the underside.
- (b) Measure and mark the centre of the tailgate, and 315mm and 625mm from the centre of the rail, 30mm from the bottom edge.
- (c) Position the aluminium in the centre of the tailgate, so that it is sitting square and flush with the top surface of the tailgate.



- (d) Drill through each of the holes in the Aluminium rail into the tailgate. Rivet the tailgate rail to the tailgate to complete the attachment.

(5). Fit Support Bar

- (a) Insert solid bar pieces into either end of hollow tube. Place the bar into the Bar Brackets and centre the hollow tube.
- (b) Adjust the hollow tube so the holes are facing to the ground (this prevents the grub screws rubbing against the tonneau).
- (c) Tighten the grub screws to secure the hollow tube into place.




(6). Fit The Tonneau Cover

- (a) To attach the cover, fit the front of Tonneau cover ("**J**" **retainer**) into the Rope Track channel and drape the cover across the tub.
- (b) Clip the side plastics under the aluminium profile first using the plastic's edge in the corners to stretch the cover.

(c) Clip the plastic on the tailgate under the aluminium profile last.

(d) To remove cover once fitted peel cover away from Aluminium clip in rail by peeling away from the edge of the plastic.




(e) **IMPORTANT:** Do not use cover corners to lift. Always use plastic edges.



How to Fit Internal Elastic Shock Cord

To be used for covering larger loads

- Tie a knot in one end of the shock cord.
- Pull shock cord through all plastic hooks.
- Feed the shock cord through loops on the cover.
- Tie a knot at the other end.
- Space the hooks as required.
- Use washers to tie off rope.



How To Easily Attach & Detach Your Clip On Cover



No more ugly pull tabs, tearing covers, or needing Arnold-like strength with this method!

- Visit the following link: <http://bit.ly/AT-CLIP>
- Or simply scan the QR code. Open your camera app and point it here to see the video! → → →

